


If you feel the winder is too tight, you may adjust it by holding the winder in one hand, and use the thumb of your other hand to push gently against the point as shown.

## U-nitt® Red Handle 10 OZ Metal Yarn Ball Winder ML702



### Instruction Manual

#### CONTENTS INCLUDED:

- 1 wool winder body
- 1 yarn guide
- 1 bobbin
- 1 instruction manual

- A. Position the yarn guide with the eye upward and insert the other end with raised hook underneath the washer and screw tight.
- B. Attach the winder to a table top with the clamp.
- C. Turn the bobbin onto the gear top clockwise until it's tight.
- D. How to thread
  1. Put the yarn end through the eye of Yarn Guide.
  2. Then go through the eye of the flyer.
  3. Lock the yarn end to the top of bobbin.
  4. Start turning the handle slowly, gradually increasing speed.